

Nova DVD-R Compatiblty List

This list is purely for a guide, and does not guarantee playback of all DVD-R discs in the players mentioned.

Last updated 14/01/2004

DVD-R Compatible	Not Reliable or Incompatible
The following players have been found to reliably play DVD-R.	The following players have been found to not reliably play DVD-R.
Aiwa XD-DV290, XD-DV370, XD-DW1	Aiwa CSDDVMIS, XD-DV170
Apex 1500, 3201, AD-660, AD-703	Apex AD-500A, AD-600A
Arcon DV88	Arcon
Daewoo	Daewoo DVG3000N, DVG6000N
Denon DVD-1000, DVD-3000, DVD-3300, DVM-3700	Denon DVD-1500
Emerson DVD-2000	Emerson
Harman Kardon DVD-5, DVD-50	Harman Kardon
Hitachi DV-B305, DVP-315U, DVP-305U	Hitachi GD3000, GD5000, GVD305, DVW1
JVC DR-M1, XV-523, XV-M567, XV-D723, XV-S45, XV-D55, XV-S40BK, XV-S60BK, XV-S65, XV-511BK, XV-FA90, XV-FA95, XV-SA70, XV-SA75	JVC XV-421BK, XV-501BK, XV-521BK, XV-525BK, XV-1000, XV-D701BK, XV-565BK, XV-M50, XV-M555BK, XV-M567GD
Kenwood DV-402, DV-403, DVCL85V	Kenwood DV-303, DVR 7000
Magnavox DVD711/171, DVD-611AT	Magnavox DVD609
Marantz DV-3100	Marantz
Memorex MVD-2026	Memorex
Mitsubishi DD-4020, DD-6000	Mitsubishi DD-2000, DD-3000, DD-4001, DD-4020
NAD T55	NAD
Pacific all models	Pacific
Panasonic DVD-S35, DVD-S75, CT27DC50, DVD-A7, DVD-A10, DVD-A100, DVD-A120U, DVD-A300, DVD-A310, DVD-K520, DVD-L10D, DVD-L110, DVD-RV55, DVD-CV50, DVD-L50D, DVD-LV55, DVD-LV75, DVD-RV20, DVD-RV30, DVD-RV31, DVD-RV32, DVD-RV41, DVD-RV60, DVD RV62, DVD-RV80, DVDX410, DMR E10, DVD-RV45KU-5, DVDT2000, PV-D4741, PV-D4761, TH15DT2	Panasonic DVDA110, DVD-C220, DVDCV40, DVDCV51, DVDH1000, DVDRP56, PVD-M2791, PV-DF2000, PV-DF2700, DVDLV60, DVDLV70, DVD-PV40
Philips DVD625, DVD940	Philips DVD701AT, DVD710AT, DVD711AT, DVD170, DVD400, DVD405, DVD751, DVD825AT, DVD850, DVD950AT, DVD756, DVD941
Pioneer DV-301, DV-333, DV-340, DV-343, DV-414, DV-434, DV-500, DV-503, DV-505, DV-525, DV-535, DV-54, DV-606D, DV-C503, DVD-V7400, DVF-07, DVL-700, PDV-LC10, DVR-1000, DVR-2000, Elite DV-05	Pioneer DV414, DV-C302D, DVC603, DV-626D, DVF727, Elite DV-09
Proline DVD2000	Proline
Proscan P8610P, PS8680Z	Proscan
Samsung DVD-611 DVD-905. DVD-M301, DVD-511, DVD-N501	Samsung DVD839, DVD709/XAA, DVD711, DVD739, DVD-C601, DVD-M101, DVDN200, DVD-N501, DVDC600,
Schneider all models	Schneider
Sharp DV-750U, DV-L70U, DV-SF20	Sharp DV-600, DVL-70TV, DV-S200
Sony DAV-S300, DVP-C600, DVP-C650D, DVP-C660, DVP-C670D, DVP-C680, DVP-FX1, DVP-CX850D, DVP-CX860, DVP-CX870D, DVP-NC600, DVP-NS300, DVP-NS400, DVP-NS700, DVP-S300, DVP-S330, DVP-S336, DVP-S350, DVP-S360, DVP-S500, DVP-S501, DVP-S520, DVP-S530, DVP-S550, DVP-S560, DVP-S570, DVP-C650D, DVP-S7700, DVP-F5, DVP-7000, DVP-7700, DVP-S9000ES, Playstation 2	Sony DVP-S3000, DVP-S7000, PV-DV30

Sylvania	Sylvania DVL100A, DVL1000
Technics A10D	
Toshiba SD-110E, SD-1200, SD-1600, SD-1700, SD-2150, SD-2200, SD-2300, SD-2700, SD-2705, SD-3006, SD-3205, SD-4205, SD-5000X, SD-6200, SD-9200, SD-P1000	Toshiba SD-9100, SD-6109C, SD-9000, SD-2006, SD-2107U, SD-2108U, SD-160L, SD-3109, SD-4109X, SD-5109, SD-2109, SD-3107, MED-300AS
Tredex TX8303	Tredex
Xbox	
X-Wave	X-Wave B171-L9
Yamaha DVD-5796, DVD-C996, DVD-S700, DVD-S796	Yamaha DVD-C900
Zenith DVC2200, DVC2250, DVC2515	